

EPA Management Method Code Listing for the Hazardous Waste Stream Report (WSR Form)

Report on the WSR Form in Item 4c (EPA Management Method Codes)	
Reclamation and Recovery	
Code	Description
H010	Metals recovery including retorting, smelting, chemical, etc.
H011	Mercury recovery (includes mercury retorting, bulb/lamp crushing and mercury vapor recovery, thermostat recovery, mercury from medical equipment recovery, mercury car switch recovery, etc.)
H015	Deployment/deactivation of airbag waste followed by metals recovery
H020	Solvents recovery
H039	Other recovery or reclamation for reuse including acid regeneration, organics recovery, etc.
H050	Energy recovery at this site; used as fuel (includes on-site fuel blending before energy recovery)
H061	Fuel blending prior to energy recovery at another site (waste generated on-site or received from off-site)
Destruction or Treatment Prior to Disposal at Another Site	
Code	Description
H040	Incineration; thermal destruction other than use as a fuel
H041	Open burning/open detonation (should be permitted under Subpart X with process code X01)
H042	Thermal desorption to remove organic contaminants from soil, sludge, or sediment by heating them in a unit called a "thermal desorber" to separate the contaminants
H070	Chemical treatment (reduction / destruction / oxidation / precipitation)
H081	Biological treatment
H090	Polymerization (LDR standard as treatment method)
H100	Physical treatment only (adsorption / absorption / separation / stripping / dewatering)
H110	Stabilization prior to land disposal at another site (encapsulation / stabilization / fixation)
H113	Stabilization to remove hazardous waste characteristics or to achieve delisting levels
H120	Combination of chemical, biological and/or physical treatment
H121	Neutralization only
H122	Evaporation
H129	Other treatment that does not include on-site disposal
Disposal	
Code	Description
H130	Surface impoundment that will be closed as a landfill (with prior treatment and/or stabilization meeting LDR treatment standard)
H131	Land treatment or application (with any prior treatment and/or stabilization)
H132	Landfill (with prior treatment and/or stabilization)
H134	Deepwell or underground injection (with or without treatment)
H136	Discharge to sewer/POTW (with prior storage - with or without treatment)
H137	Discharge to NPDES permit (with prior storage - with or without treatment)
Transfer Off-site	
Code	Description
H141	Storage & Transfer -The site receiving this waste stored/bulked and transferred the waste with no reclamation, recovery, destruction, treatment, or disposal at that site